

Technical Data Sheet

AS-5560 Timber Adhesive 5560



Physical Properties

Appearance:
Viscous liquid

Colour:
Clear

Storage:
Store in a dry and cool place with temperature below 30 °C.

Shelf life:
12 months

Packaging:

Content	Quantity/ carton
500 g Bottle	24
5 kg Jerry Can	4
20 kg Jerry Can	1
20 kg Carton	1

Description

ALSEAL Timber Adhesive 5560 is a fast setting water-based adhesive suitable for bonding in wood working applications. It is white colour before drying but will turn into a clear and colourless dried film. It dries to form a strong bond between timbers, and is resistant to normal hygrometric movements of wood and the thermal expansion of substrates. It can be applied smoothly and can be cleaned up with water.

Features

- ◆ Fast setting
- ◆ High solid content (Low water content)
- ◆ Bonds moisture sensitive timber
- ◆ Dry colour: Clear
- ◆ Notched trowel ridges will hold firm

Applications

Ideal for the bonding of moisture sensitive timber in wood flooring applications, including parquet, industrial parquet and floorboards of all types of wood, multi-layer pre-finished parquet of small format. It may be used on cement-based screeds, wooden substrates, shipboard panels, Masonite panels etc.

Technical Data

Solid content	: 57%
Viscosity	: 10,000 cps
Specific gravity	: 1.08
VOC content (USEPA Method 24)	: 28.26 gm/L

Approvals/ Specifications

AS-5560 meets the requirements of the following specifications:

- Low VOC - USEPA Method 24 SCAQMD Method 303-91 under SCAQMD Rule 1168

Usage Instructions

Substrate Preparation

- Substrates must be dry, absorbent, level, sound, free of dust, loose particles, paint, wax, oil, rust and traces of gypsum.
- The moisture content of the screed must be lower than the maximum prescribed by the timber manufacturer.
- Check moisture throughout the entire thickness of substrates, using carbide hygrometer.
- Floating screeds over insulation or light weight (e.g. light weight concrete) and slabs on grade must be provided with a moisture barrier to prevent rising damp.
- To repair cracks in the substrate, consolidate screeds and level uneven surfaces.

Adhesive Applications

- Stir the adhesive before using. Remove the skin surface, if any.
- Apply the adhesive to the substrate with notched trowel suitable to the format.
- The open time is 30 minutes under normal temperature (10 °C to 40 °C) and humidity conditions, which must be taken into consideration when applying the adhesive.
- If skin forms on the adhesive before parquet installation, the adhesive must be removed and replaced.



AS-5560 Timber Adhesive 5560

Parquet Installation

1. The parquet to be installed must be stored in a dry, sheltered area not subject to the vapour condensation and must be insulated from the ground.
2. Check the moisture content of the timber and the ambient humidity before installation.
3. Press the wood parquet firmly onto the wet adhesive to ensure good contact.
4. Leave a gap of approximately 10mm width around the perimeter, columns, and any elements crossing the floor.
5. Do not bond edges of wood strips together. (follow the parquet manufacturer's recommendations for installation)

Bottle Application

1. Substrates must be dry, absorbent, flat, and free of loose particles, paint, wax, oil, or rust.
2. All substrates should fit tightly, with no saw marks or burnishing of the substrates to be bonded.
3. Apply AS-5560OV by squeezing it out from the bottle to the substrates, and brush or roll with roller if necessary.
4. Substrates should be assembled within a few minutes and then tightly pressed or clamped.
5. Wipe off excess of adhesive immediately with a dry or lightly damp cloth. If skin forms on the adhesive before substrates are assembled, the adhesive must be removed and replaced.

Curing Time

Floors are set to light traffic after 48 hours. For parquet polishing, wait for at least 10 days to ensure that the wood has reached the proper stability and that the adhesive is completely dry.

Consumption

Depending on the type of substrates and notched trowel selection, the adhesive consumption range from 0.6 kg to 1.0 kg / m². For laminated plank, the recommended adhesive coverage is at least 80 %. For solid wood, minimum 95 % adhesive coverage is required.

Limitation

Not recommended for the following applications:

- ◆ Use in very cold areas. In cold weather, rooms must be heated.
- ◆ Use on anhydrite or magnesium screed.
- ◆ Use on screeds where there may be possible rising damp (must insert a moisture barrier between ground and the screed).
- ◆ Use if the screed is not dry and has a moisture content higher than recommended by the wood manufacturer (check moisture content throughout the entire thickness).

Caution

Keep out of reach of children. Safety data sheet available on request. For further health and safety information, consult the latest safety data sheet.

Disclaimer

Every endeavour has been made to ensure that the information given herein is true and reliable but it is given only for the guidance of our customers. The company cannot accept any responsibility for the loss or damage that may result from the use of the information, due to the possibility of variations of processing or working conditions and of workmanship outside our control. Users are advised to confirm suitability of this product by their own tests.